




Change WiFi Password & Configure Comms in Mysolaredge app

You may need to reconfigure your inverter communication in certain cases, such as when your Wi-Fi network or password has changed. To configure your inverter communication:



1. click "**Inverter Communication**" in the menu.

2. Refer to the steps above, under "**Connect to Your Inverter.**"



3. The status of your Wi-Fi connection should be 'disconnected'. To connect to your Wi-Fi network, click "configure."
4. Select your preferred wireless network and insert a password, then click "join." "You will now be connected to your Wi-Fi network. To confirm the connection is successful, click on "inverter communication" in the menu. Connect to the



inverter and verify the status as S_OK.

5. If you run into any trouble with the above instructions, please copy the link below to view the Wi-Fi connection video

[mySolarEdge App: Configuring your inverter's communication \(youtube.com\)](https://www.youtube.com/watch?v=...)